

# KOLPIN

THE LEADER IN ALL-TERRAIN INNOVATION

## ATV DIAMOND PATTERN TIRE CHAIN INSTALLATION INSTRUCTIONS

1. Lay chains out flat and remove all twists and tangles. Arrange chains so that the side with the sharp open hooks is facing down and away from the tire.
2. Double-check to make sure that the sharp, open-hook side of the tire chains is facing down. Otherwise, if the hooks are facing up, the studs will be in the wrong direction after installation, which may cause tire damage.
3. On one end of chains, identify the "Gathering Rings" and on the other end you will have 2 tails protruding from the middle of the chain. Also on one end will see 2 small "boomer" side chain fasteners.
4. Drive tire over the top of chains and leave about 1 foot of chain sticking out one end of the tire.
5. Pull chains up and over the tire as far as you can and then bring up the chain remaining on the ground to meet it.
6. On the inner side of the tire, take the "boomer" hook in hand, hook it through the nearest side chain link, fold it back to itself and hook on the connection link. ( g 1.) You will have a number of unused links beyond the fastener. Make note of the number of links.
7. Do the same procedure at #5 on the outside of the tire ( g 2.) Make sure to count out the same number of unused links beyond the "boomer" fastener to make certain the chains will stay centered on the tire.
8. Take 1 of the 2 chain tails protruding from the center of the chain, put it through the corresponding gathering ring and pull taut. ( g 4,5,6.) Pull tail through ring then pull down toward the side chain on the corresponding side and attach with shackle ( g 7,8,9.).
9. Do the same procedure with the other chain tail and pull taut.
10. You may need to re-tighten your side chain "boomer" fasteners taking up as much slack as possible.
11. Slowly operate your vehicle a short distance, step off, inspect and re-tighten chains if necessary.
12. Enjoy your new traction product.

